## **SIEMENS**

Data sheet 3RS7005-2KW00



Signal converter 24-240 V AC/DC, 3-way separation Input: 0-10 V, 0/4 - 20 mA; Output: 0-50/100 Hz/1/10 kHz; Spring-type terminal (push-in)

product brand name	SIRIUS
product category	Signal converter
product designation	multi-range converters
design of the product	active, switchable
product type designation	3RS70
General technical data	
display version LED	Yes
number of channels	1
consumed active power	0.34 W
insulation voltage for overvoltage category III according to IEC 60664 with degree of pollution 3 rated value	300 V
surge voltage resistance rated value	4 000 V
protection class IP	IP20
shock resistance according to IEC 60068-2-27	sinusoidal half-wave 15g / 11 ms
vibration resistance according to IEC 60068-2-6	6 150 Hz: 2 g
reference code according to IEC 81346-2	Т
Substance Prohibitance (Date)	03/25/2015
Supply voltage	
supply voltage at AC	
• at 50 Hz rated value	24 240 V
at 60 Hz rated value	24 240 V
supply voltage at DC rated value	24 240 V
supply voltage frequency rated value	60 50 Hz
operating range factor supply voltage rated value	
• at AC at 50 Hz	0.8 1.1
• at AC at 60 Hz	0.8 1.1
• at DC	0.8 1.1
Precision	
relative metering precision	0.1 %
relative linearity deviation	0.05 %
temperature drift per °C	0.015 %/°C
limit frequency	30 Hz
Main circuit	
type of voltage	AC/DC
Inputs/ Outputs	
input voltage	30 V
property of the output short-circuit proof	Yes
type of signal at input	0 10 V, 0 20 mA, 4 20 mA
type of signal at output	0 50 Hz, 0 100 Hz, 0 1 kHz, 0 10 kHz
input impedance of current input maximum	100 Ω

input impedance of voltage input minimum	330 kΩ
Electromagnetic compatibility	330 KU
EMC emitted interference according to IEC 60947-1	Environment B
EMC immunity according to IEC 60947-1	corresponds to degree of severity 3
conducted interference	Corresponds to degree or severity 3
due to burst according to IEC 61000-4-4	1 kV 5/50 ns
due to burst according to IEC 01000-4-4     due to conductor-conductor surge according to IEC	1 kV
61000-4-5	I NV
field-based interference according to IEC 61000-4-3	10 V/m
electrostatic discharge according to IEC 61000-4-2	6 kV contact discharge / 8 kV air discharge
Galvanic isolation	
design of the electrical isolation	3 paths
galvanic isolation	
<ul> <li>between input and output</li> </ul>	Yes
<ul> <li>between the outputs</li> </ul>	No
<ul> <li>between the inputs</li> </ul>	No
between the voltage supply and other circuits	Yes
Connections/ Terminals	
type of electrical connection	spring-loaded terminals
type of connectable conductor cross-sections	
• solid	1x (0.25 2.5 mm²)
<ul> <li>finely stranded with core end processing</li> </ul>	1x (0.25 1.5 mm²)
<ul> <li>finely stranded without core end processing</li> </ul>	1x (0.25 2.5 mm²)
• for AWG cables solid	1 x (20 14)
for AWG cables stranded	1x (20 14)
connectable conductor cross-section	
• solid	0.25 2.5 mm²
finely stranded with core end processing	0.25 1.5 mm <sup>2</sup>
finely stranded without core end processing	0.25 2.5 mm²
AWG number as coded connectable conductor cross section	
***************************************	
• solid	20 14
<ul><li>solid</li><li>stranded</li></ul>	20 14 20 14
• stranded	
• stranded Installation/ mounting/ dimensions	20 14
• stranded Installation/ mounting/ dimensions mounting position	20 14 any
stranded Installation/ mounting/ dimensions mounting position fastening method	20 14  any snap-on mounting
• stranded  Installation/ mounting/ dimensions  mounting position  fastening method height	20 14  any snap-on mounting 93 mm
• stranded Installation/ mounting/ dimensions mounting position fastening method height width	20 14  any snap-on mounting 93 mm 17.5 mm
• stranded Installation/ mounting/ dimensions mounting position fastening method height width depth	20 14  any snap-on mounting 93 mm 17.5 mm
• stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing	20 14  any snap-on mounting 93 mm 17.5 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting	any snap-on mounting 93 mm 17.5 mm 72.5 mm
stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • with side-by-side mounting  — forwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method height width depth required spacing ● with side-by-side mounting — forwards — backwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts	20 14  any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method height width depth  required spacing  ● with side-by-side mounting — forwards — backwards — backwards — upwards — downwards — at the side ● for grounded parts — forwards	20 14  any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — backwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — a the side  ● for grounded parts  — forwards  — backwards  — upwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — at the side  ● at the side  ● upwards  — backwards  — upwards  — at the side	20 14  any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method height width depth  required spacing  ● with side-by-side mounting — forwards — backwards — backwards — upwards — downwards — at the side  ● for grounded parts — forwards — backwards — at the side — backwards — at the side — downwards — at the side — downwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  — at the side  — downwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  ● for grounded parts  — forwards  — backwards  — backwards  — upwards  — at the side  — downwards  ● for live parts  — forwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method height width  depth  required spacing  ● with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  ● for grounded parts — forwards — backwards — upwards — at the side  ● for grounded parts — forwards — backwards — upwards — at the side — downwards ● for live parts — forwards — backwards — backwards — backwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  ● for live parts  — forwards  — backwards  — upwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — backwards  — obackwards  — in the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  ● for live parts  — forwards  — backwards  — upwards  — backwards  — upwards  — downwards  — obackwards  — upwards  — backwards  — upwards  — backwards  — upwards  — downwards	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  ● for live parts  — forwards  — backwards  — upwards  — at the side  — downwards  — backwards  — upwards  — backwards  — backwards  — backwards  — backwards  — at the side  — downwards  — backwards  — at the side	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
• stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • with side-by-side mounting  — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — backwards — upwards — the side  • for live parts — forwards — backwards — upwards — at the side — downwards  • for live parts — forwards — backwards — upwards — backwards — upwards — downwards — backwards — upwards — backwards — upwards — at the side  Ambient conditions	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
● stranded  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  ● with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  ● for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  ● for live parts  — forwards  — backwards  — upwards  — at the side  — downwards  — backwards  — upwards  — backwards  — backwards  — backwards  — backwards  — at the side  — downwards  — backwards  — at the side	any snap-on mounting 93 mm 17.5 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm

during operation
 during storage
 during transport
 telative humidity during operation

Certificates/ approvals

**General Product Approval** 

**Declaration of Conformity** 



Confirmation









**Test Certificates** 

Marine / Shipping

other

Type Test Certificates/Test Report



Confirmation

## **Further information**

Siemens has decided to exit the Russian market (see here).

https://press.siemens.com/global/en/pressrelease/siemens-wind-down-russian-business

Siemens is working on the renewal of the current EAC certificates.

Please contact your local Siemens office on the status of validity of the EAC certification if you intend to import or offer to supply these products to an EAC relevant market (other than the sanctioned EAEU member states Russia or Belarus).

Information on the packaging

https://support.industry.siemens.com/cs/ww/en/view/109813875

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RS7005-2KW00

Cax online generator

 $\underline{\text{http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en\&mlfb=3RS7005-2KW00}$ 

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)


https://support.industry.siemens.com/cs/ww/en/ps/3RS7005-2KW00

 $Image\ database\ (product\ images,\ 2D\ dimension\ drawings,\ 3D\ models,\ device\ circuit\ diagrams,\ EPLAN\ macros,\ ...)$ 

http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RS7005-2KW00&lang=en

**Characteristic: Derating** 

https://support.industry.siemens.com/cs/ww/en/ps/3RS7005-2KW00/manual



last modified: 12/23/2020 🖸

